

Assembly Instructions










! Warning! Chair arms are for gaming support only.
To avoid damage or injury, do not sit on the arms. Do not
use arms to EXIT from the chair or to MOVE or LIFT the chair.



! WARNING
Crush Hazard
Keep hands and
fingers away

A		1
B		1
C		1
D		2
E		1
F	M6	1
G	M8*25	4
H	Ø8*Ø18	4
I		6
J	M8*40	6
K		1
L	Ø8*Ø15	6



If there are any parts missing or you need further assistance, contact X Rocker at:
www.xrockeruk.com/pages/support