




# **PANTHER XL REVERSIBLE GAMING DESK**





















## **Assembly Instructions**




**Need Help? Contact X Rocker at : [www.xrockeruk.com/pages/support](http://www.xrockeruk.com/pages/support)**




**IMPORTANT: You must keep your original retail receipt as proof of purchase.**

**Please retain for future reference**






<p>1.</p>  <p>X1</p>	<p>2.</p>  <p>X1</p>	<p>3.</p>  <p>X1</p>	<p>4.</p>  <p>X1</p>
<p>5.</p>  <p>X2</p>	<p>6.</p>  <p>X1</p>	<p>7.</p>  <p>X1</p>	<p>8.</p>  <p>X1</p>
<p>9.</p>  <p>X2</p>	<p>10.</p>  <p>X2</p>	<p>11.</p>  <p>X2</p>	<p>12.</p>  <p>X1</p>
<p>A.</p>  <p>M6X12 X16</p>	<p>B.</p>  <p>M6X30 X8</p>	<p>C.</p>  <p>M6X50 X8</p>	<p>D.</p>  <p>M8X40 X2</p>
<p>E.</p>  <p>M8X40 X4</p>	<p>F.</p>  <p>X3</p>	<p>G.</p>  <p>X5</p>	<p>H.</p>  <p>X8</p>



**LEFT**





Screw inner bolts first, outer bolts second.




M6X12





M6X50





Cx8


M6X12











Ax4




Fx3




RIGHT







M6X50




Cx8



M6X12



Ax4



Fx3