


XRocker®

Cougar XL

Gaming Desk

Assembly Instructions



Need Help? Please visit the following webpage!

www.xrockeruk.com/pages/support

IMPORTANT: You must keep your original retail receipt as proof of purchase.

Welcome to X Rocker!

Thank you for purchasing this X Rocker gaming desk. You are now close to enhancing your favourite games with glorious audio!

To get started, please assemble the desk using these assembly instructions, and then follow the instructions in the user manual to **get rocking!**

Tools needed



Allen Key
















Screwdriver









2 person build

Box Contents: Parts



<div>1</div> <div></div> <div>X1</div>	<div>2</div> <div></div> <div>X1</div>	<div>3</div> <div></div> <div>X1</div>	
<div>4</div> <div></div> <div>X2</div>	<div>5</div> <div></div> <div>X1</div>	<div>6</div> <div></div> <div>X1</div>	
<div>7</div> <div></div> <div>X1</div>	<div>8</div> <div></div> <div>X2</div>	<div>9</div> <div></div> <div>X4</div>	
<div>10</div> <div></div> <div>X1</div>	<div>11</div> <div></div> <div>X1</div>	<div>12</div> <div></div> <div>X1</div>	<div>13</div> <div></div> <div>X1</div>


Box Contents: Fittings

<div>A</div> <div></div> <div>Small x38</div>	<div>B</div> <div></div> <div>Medium x8</div>	<div>C</div> <div></div> <div>Large x6</div>
<div>E</div> <div></div> <div>x4</div>	<div>F</div> <div></div> <div>x3</div>	<div>G</div> <div></div> <div>x1</div>




Assembly Instructions


Step 1:

4		x2
A		x8




Step 2:






5		x1
6		x1
A		x8




Assembly Instructions








Step 3:



B		x8
E		x4
4		x2
5		x1
6		x1


Step 4:



A		x12
1		x1
2		x1
3		x1
9		x4
12		x1
13		x1


Assembly Instructions

Step 5:




A  x10


C  x6

10  x1

Step 6:




F  x3

11  x1

Assembly Instructions

Step 7:



How to adjust height

NOTE: This is a 2-person process.

Remove all unstable/fragile appliances from the desktop.

To adjust the height 1 person should support the weight and desktop whilst the other person removes the screws in the legs (please follow step 2 in reverse).

Adjust the height up/down and align the screw holes when the desired height has been reached.

Place the screws back into the legs, ensuring that they are tight.

NOTE: Please ensure that all screws are used, failure to use all may result in the damage to the desk and reduce the maximum weight it can take.

Need Help? Please visit the following webpage!
www.xrockeruk.com/pages/support

IMPORTANT: You must keep your original retail receipt as proof of purchase.

Love your product? Show us on social!

Facebook: X Rocker Nation

Instagram: XRockerGaming

Twitter: XRockerGaming