

XRocker

Panther Gaming Desk




Need Help? Email: Service@XRockerNation.co.uk

Phone: 01274 683 109 www.XRockerNation.co.uk

IMPORTANT: You must keep your original receipt as proof of purchase.


PARTS




A x 10




B x 10




C x 8




D x 8




E x 1




F x 1




P1 x 1




P2 x 1




P3 x 2



P4 x 2




P5 x 1




P6 x 2



P7 x 4



P8 x 1



P9 x 1



P10 x 1




P11 x 1


The following tools are needed but not included





1.





2.






3.




4.







5.



6.



7.



8.

