


XRocker®

LYNX V2 GAMING DESK

Assembly Instructions



Need Help? Contact X Rocker at: www.xrocker.com/pages/support

IMPORTANT: You must keep your original retail receipt as proof of purchase

Please retain for future reference

Parts list

①



x4

②



x6

③



x8

④



x16

⑤



x8

⑥



x4

A



x2

B



x1

C



D1



x1

D2



x1

E



x1

F



x1

G



x2

H



x1

I



x1

J



x2

K



x2

L




x1




Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.


Step 1.




Step 2.



Step 3.



Step 4.



Step 5.



Step 6.

