X ROCKER GAMING BUNK BED

XRocker.

Need Help ? Contact X Rocker at :
www.xrockeruk.com/pages/support
IMPORTANT: You must Keep your original retail receipt as proof of purchase.

⚠ Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area. Small parts may cause a choking hazard.

• Parts of the assembly will be easier with 2 people.

• Make sure you have enough space to layout the parts before starting.

• Assemble the item as close to its final position (in the same room) as possible.

• Dispose of all packaging carefully and responsibly.

• Place the product on flat and steady surface during use.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Keep these instructions for further use.

• To ensure an easier assembly we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.

Care and maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.

⚠ Safety and Care Advice

WARNING
THE MATTRESS SURFACE LEVEL SHOULD
**NOT BE ABOVE THIS LINE**
↓

Important: Please note the maximum mattress height is indicated on the vertical bar on the left hand side of the opening at the top of the ladder.
This is legal requirement and it is vital that the mattress do not exceed this mark.
Note: The maximum thickness of the mattress is 160 mm.

This bunk bed conforms to BS EN 747-1 & -2: 2012 +A1:2015

160

DO NOT REMOVE THE LABEL FROM THE BED

a) **WARNING** "High beds and the upper bed of bunk beds are not suitable for children under six years due to the risk of injury from falls";
b) **WARNING** "Bunk beds and high beds can present a serious risk of injury from strangulation if not used correctly. Never attach or hang items to any part of the bunk bed that are not designed to be used with the bed, for example, but not limited to ropes, strings, cords, hooks, belts and bags"
c) **WARNING** "Children can become trapped between the bed and the wall, a roof pitch, the ceiling, adjoining pieces of furniture (e.g. cupboards) and the like. To avoid risk of serious injury the distance between the top safety barrier and the adjoining structure shall not exceed 75 mm or shall be more than 230 mm";
d) **WARNING** Do not use the bunk bed/high bed if any structural part is broken or missing;
e) Always follow the manufacturer's instructions;
f) The recommended size of the mattress to be used with the bed is 1900mm x 900mm, Maximum mattress thickness:160mm;
g) Bed must be aired to maintain a low humidity and to stop moisture in its surroundings.
h) This complies with the requirements of the European Safety Standard BS EN 747-1 & -2: 2012 +A1:2015.
i) Do not allow more than 1 person on the upper bunk at one time.
j)This product is not suitable for children under 6 years.

PARTS

Components - Panels

1 Post 01 x 1

2 Post 02 x 1

3 Post 03 x 1

4 Post 04 x 1

5 Side Rail x 2

7 End Guard Rail x 2

12 Front Guard Rail x 1

13 Rear Guard Rail x 1

14a Slats x 24

15 Plastic Plug x 48

16 Slat Spacer x 23

22 Ladder x 1

30 Wall Bracket x 2

31 Bracket x 4

49a Front Desktop x 1

49b Rear Desktop x 1

50a Main Shelf x 1

5

Components - Panels

**50b** Left Shelf x 1

**50c** Right Shelf x 1

51 Bottom Shelf x 1

52 Rear Mesh Panel x 2

53 Side Mesh Panel x 5

54a Desk Support Rail 02 x 2

54b Desk Support Rail 01 x 3

55a Main Shelf Support x 1

55b Left Shelf Support Frame x 1

55c Right Shelf Support Frame x 1

56 Lower Shelf Support x 1

57 Pad x 2

63 Cable Cap x 3

6

Components - Fittings

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied as required.

(N)	(B)	(C)
17mm Bolt M6 x 43	25mm Bolt M6 x 7	30mm Bolt M6 x14
(D)	(E)	(H)
38mm Bolt M6x33	60mm Bolt M6 x 6	M6 x 2
(I)	(J)	(K)
M6 Spring washer x 8	M6 Metal washer x 8	M6 Plastic washer x 8
(L)	(M)	
Allen Key x 1	Wrench x 1	

Tools required

Ruler/tape measure

Ruler - User this ruler to help correctly identity the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

Attach End Guard Rail [7] to Post 01 [1] and Post 02 [2] with C.

M6 X30 mm
CX4

L X 1

4mm

75%

Step 2

Attach End Guard Rail [7] to Post 03 [3] and Post 04 [4] with C.

M6 X 30 mm
CX4

L X 1

4mm

75%

Assembly Instructions

Attach Rear Guard Rail 13 to Post 02 2 and Post 03 3 with C , I , J , K .

M6 Plastic washer	M6 Metal washer	M6 Spring washer	M6 X 30 mm	
KX4	JX4	IX4	CX4	L X 1

4mm

75%

Step 4

Insert Ladder 22 into Post 04 4 with B .

You may need to adjust the tread manually to insert to the holes one by one on Post 04 4 .

M6 X 25 mm	
BX5	L X 1

4mm

75%

Assembly Instructions

Step 5

a:Attach Front Guard Rail 12 to Post 01 1 with C , I , J , K , and Post 04 with B , I , J , K .

b:Attach Ladder 22 to Front Guard Rail 12 with N .

M6 Plastic washer KX4	M6 Metal washer JX4	M6 Spring washer IX4	M6 X 30 mm CX2	M6 X 25 mm BX2	M6 X 17 mm NX1	L X 1

Step 6

Attach Left Shelf Support Frame 55b and Right Shelf Support Frame 55c to Main Shelf Support 55a with D .

M6 X 38 mm DX4	L X 1

# Assembly Instructions

Step 7

a: Attach Left Shelf Support Frame 55b to Post01 1 and Post 02 2 with N .

b: Attach Right Shelf Support Frame 55c to Post 03 3 and Post 04 4 with N .

c: Attach Main Shelf Support 55a to Post 02 2 and Post 03 3 with E .

M6 X 17 mm NX4	M6 X 60 mm EX2	L X 1

75%

4mm

Step 8

a: Attach Side Rail 5 to Post 01 1 and Post 02 2 with N .

**b:** Attach Side Rail 5 to Post 03 3 and Post 04 4 with N .

M6 X 17 mm NX4	L X 1

75%

4mm

11

Assembly Instructions

Step 9

Attach Desk Support Rail 01
54b x3 to Desk Support Rail 02
54a x2 with D .

75%

4mm

| M6 X 38 mm DX6 | L X 1 |

Step 10

a:Attach Desk Support Rail
02 54a to Side Rail 5 with D .

b:Attach Desk Support Rail
02 54a to Post 02 2 and
Post 03 3 with E .

75%

4mm

| M6 X 38 mm DX2 | M6 X 60 mm EX2 | L X 1 |

Assembly Instructions

Step 11

a:Attach Lower Shelf Support 56 to Bottom Shelf 51 with D .

b:Attach Pad 57 x2 to Lower Shelf Support 56 .

75%

4mm

M6 X 38 mm
DX4

L X 1

Step 12

Attach Lower Shelf Support 56 to Post 01 1 and Post 02 2 with E .

75%

4mm

M6 X 60 mm
EX2

L X 1

# Assembly Instructions

Step 13

**a:** Attach Left Shelf `50b` to Left Shelf Support Frame `55b` with **D** .

b: Attach Right Shelf `50c` to Right Shelf Support Frame `55c` with **D** .

c: Attach Main Shelf `50a` to Main Shelf Support `55a` with **D** .

75%

4mm

M6 X 38 mm DX11

L X 1

Step 14

Attach Cable Cap `63` **x3** to Rear Desktop `49b` .

Twist the X cover to open the cable grommet. Then pass cables through the desktop as desired. Then reassemble the X cover and twist to close the cable grommet again

Assembly Instructions

Step 15

Attach Rear Desktop 49b to Desk Support Rail 01 54b with D .

49b

54b

54b

54b

D

D

D

75%

4mm

M6 X 38 mm
DX3

L X 1

Step 16

Attach Front Desktop 49a to Desk Support Rail 01 54b with D .

49a

54b

54b

54b

D

D

D

75%

4mm

M6 X 38 mm
DX3

L X 1

15

Assembly Instructions

Step 17

Attach Side Mesh Panel `53` **x2** to Post 03 `3` and Post 04 `4` with `N` .

The edgefolds on mesh panels should be towards inside of bed.

75%

4mm

M6 X 17 mm NX8

L X 1

Step 18

Attach Side Mesh Panel `53` **x3** to Post 01 `1` and Post 02 `2` with `N` .

The edgefolds on mesh panels should be towards inside of bed.

75%

4mm

M6 X 17 mm NX12

L X 1

16

Assembly Instructions

a: Attach Rear Mesh Panel 52 **x2** to Post 02 2 and Post 03 3 with N .

b: Attach Rear Mesh Panel 52 **x2** together with N H .

The edgefolds on mesh panels should be towards outside of bed.

|			
M6 X 17 mm NX10	M6 HX2	L X 1	MX 1

Assembly Instructions

a: Secure the Slats 14a x24 to Rear Guard Rail 13 and Front Guard Rail 12 .

b: Secure the Plastic Plug 15 x48 to Rear Guard Rail 13 and Front Guard Rail 12 .

a:

b:

Assembly Instructions

Secure Slat Spacer 16 x23 to Slats 14a x24 .

Attach Bracket 31 x4 to End Guard Rail 7 x2 with N .

75%

4mm

|	M6 X 17
	NX4
	L X 1

19

Assembly Instructions

Assembly is complete

4mm

30

For your safety, it is imperative to fix your furniture to the wall. Please source the right wall mounting hardware according to the nature of wall.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:

- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

⚠ Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualifed tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.
2: Ensure you use the recommended drill bit to match the wall plug and hole size.
3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls

You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug

For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug

For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads

For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

⚠ Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.